

POSTER SIGN HOLDER



Attach the first frame section onto base using Phillips head screws.



Repeat for the mid and top frame sections.



Use the knobs to adjust the tilt of the frames and insert graphics.

